

Combination Power supplies


Z-LASER

Intelligent Solutions in Light

1pc laser
ZB, ZD, ZF-pe-F or ZT



+



WPSB-3.5
with Texas socket

1pc laser
(ZB, ZD, ZF-pe-F OR ZT)
can be connected to **1pc WPSB-3.5.**

4pcs laser
ZB, ZD, ZF-pe-F or ZT



+



VB4 Distributor box
- 4pcs Texas socket for connecting the lasers
- 1pc Texas socket for connecting the power supply

+



WPS-3.5
with Texas plug

Up to 4pcs lasers
(4xZB OR 4xZD OR 4xZF-pe-F OR 4xZT)
can be connected to
1pc VB4 AND 1pc WPS-3.5.

Same applies to ZM12 & ZM18-lasers:

1pc laser can be connected to
1pc WPS-5-M12 .

4pcs lasers can be connected to
- 1pc VB4-M12 distributor box and
- 1pc WPS-5-M12 power supply.

